

# DEPRAG

## Operating Instruction Booklet

### Pneumatic Plier

48-271

807672 A

Dear Customer:

This tool is the result of more than 70 years of experience in the design and manufacturing of pneumatic tools for the industrial market.

We kindly ask that you read these operating instructions carefully so that you will be able to use this tool safely and for many years to come. If you need additional information, please contact your DEPRAG

Representative, one of our international support offices or us direct at DEPRAG. We will be happy to answer any questions. Please visit our web site: [www.deprag.com](http://www.deprag.com)

## 1 List of Contents

1	LIST OF CONTENTS .....	2
2	SAFETY TIPS .....	3
2.1.	General Safety Tips.....	3
2.2.	Safety Tips for machines for cutting and squeezing .....	4
2.3.	Owner Obligation.....	5
2.4.	Operator Obligation .....	5
2.5.	Warranty and Liability .....	6
2.6.	Symbol Description .....	7
2.7.	Observe Environmental Regulations .....	9
3	DESIGNATED EQUIPMENT USE .....	9
4	INSTALLATION.....	10
5	OPERATION .....	11
6	HANDLING.....	11
7	ASSEMBLY - DISASSEMBLY .....	12
7.1.	Spare Parts Drawing .....	14
7.2.	Dimensional Drawing.....	15
8	MAINTENANCE AND UPKEEP .....	16
8.1.	Wear Parts .....	16
8.2.	Trouble Shooting.....	17
9	DELIVERY CAPACITY .....	17
10	STORAGE .....	18
11	TECHNICAL DATA.....	18
12	DISPOSAL.....	18
13	CONFORMITY DECLARATION .....	19
14	SERVICE LOCATIONS AND AUTHORIZED PARTNERS .....	20

## 2 Safety Tips

### 2.1. General Safety Tips



**Before operating tool make sure to carefully read and observe this operating instruction.**

Generally, the operator of the equipment and/or machinery is responsible for the equipment's perfect condition and operation, while observing all necessary safety regulations. The equipment and/or machinery has been constructed in accordance with the newest level of technology while recognizing all necessary safety-related requirements. Nevertheless, while operating the equipment and/or machinery there is a change of bodily harm to the operator as well as damage to equipment and/or machinery and other property. Operate the equipment and/or machinery only if equipment/machinery

- Is used for the task it was designed for
- is in perfect working condition and safe to use.


It is important to observe the technical data of the equipment, especially in regards to the environmental temperatures. The designated area of use for this equipment is clearly described in chapter *Designated Equipment Use* and those requirements have to be observed as well. Prerequisite for the safe conduct and the uninterrupted operation of the equipment, is the knowledge of the basic safety tips and the safety regulations. Additionally, all current regulations for a safe operational area, for accident-prevention guidelines of electrical and mechanical installations, as well as noise suppression demands must be observed. During any maintenance or repair work, a clean work surface is recommended. Also, it is not recommended to either eat or smoke during repair or maintenance. Arbitrary changes made to the equipment, which alters its designated use, voids the warranty and cancels the manufacturers liability.

- The tool is not insulated to protect against an electrical power surge.
- It is not recommended to use this tool in explosive hazardous environments, unless it was specifically designed for such a use.
- During the disconnection or reconnection of the tool from the compressed air, an injury is possible because of a whipping pressure-hose.

The operating instruction booklet, especially the safety symbols and safety tips attached to the equipment or included in the documentation, must be observed at all times by all persons getting into contact with the equipment.

## 2.2. Safety Tips for machines for cutting and squeezing



- Keep your hands away from the cutting/pressing opening! Tool inserts with a wide “mouth” especially may cause injuries.
  - Make sure to never operate the tool holding it towards yourself or any other person.
  - Cut-off pieces or work parts of especially brittle material may be catapulted off – so watch out! When starting the tool, always pay attention to adjust the operating tool tip so that this risk will be reduced. Make sure to wear protective goggles!
  - Before putting the tool back down make sure to secure the lever, in order to avoid inadvertent start of tool.
  - When connecting/disconnecting tool to/from air supply, take absolute care NOT to activate operating lever. After using and before putting it down, tool should be disconnected from air supply.
  - Check plier inserts prior to operation and make sure they are not worn. If necessary, install new inserts (injuries may be caused by using worn/broken inserts).
- 
- The plier should only be used for the intended application. Tool may be damaged by cutting or bending tests, in the attempt to increase its power capability.
  - For exchange of inserts, tool has to be disconnected from power/air supply .
  - Maximum operating (flow) pressure must not be exceeded. Make sure to use a pressure regulator so that air flow pressure is checked before reaching the tool.
  - Do not wear any loose clothing or jewellery. They may get caught on the moving parts. Protect long hair by using a hair net.

## 2.3. Owner Obligation

The owner is obliged to only let persons operate the equipment, who

- are familiar with basic work environment safety rules and accident-preventing regulations. Also, those persons must have been instructed in the correct use of the equipment.
- have read and understood all safety and warning notifications in the Operating Instruction Booklet, as well as all other documentation pertaining to this equipment.
- check and confirm at regular intervals, that a safety oriented operation is guaranteed.

Only qualified and authorized personnel is allowed to operate, maintain and repair this equipment. A malfunction, which impairs operator safety, must be immediately removed.

## 2.4. Operator Obligation

Personnel, who is engaged in the operation of the equipment, must always be committed to

- observe the basic safety and accident preventing regulations,
- read and observe the safety and warning notifications of this operating instruction booklet.

## 2.5. Warranty and Liability

Unless otherwise specified, our “General Sales and Delivery Conditions” apply. Warranty and liability claims in regards to persons or equipment damages are invalid, if one or several of the following causes apply:

- Use of the equipment in a non-designated application.
- Improper installation, operation, service or maintenance of the machine.
- Operation of the machine with either defective or removed safety and protection devices.
- Non-observance of the requirements stated in the operating instruction booklet, in regards to transportation, storage, mounting, installation, operation, maintenance and service of the equipment.
- Structural change or adjustment on the equipment to a non-designated use.
- Inadequate supervision of wear parts.
- Improper repair, inspection or maintenance.
- Catastrophic cases because of a war, acts of god or other reasons which are beyond our control.

## 2.6. Symbol Description



Read and observe the Operating Instruction Booklet, prior to and during operation of tool.



### **DANGER**

Reference to an immediate danger to a person. May lead to serious injuries or even death, if unobserved!



Properly recycle environmentally damaging grease, cooling agents or detergents



### **RECOMMENDATIONS**

Important or additional information on the equipment or in the documentation



Use eye protection or wear safety goggles




Wear hearing protection



Warning against hand-injuries.

Attention: Keep away your hands from areas, which are marked with this symbol!



Hands may be crushed, seized or otherwise injured.



## ESD-protected area

Equipment may be damaged or destroyed by an electrostatic discharge.

Maintenance and repair on hydraulic and pneumatic equipment may only be performed by specially trained personnel!



Disconnect equipment from air supply, prior to repair of pneumatic or hydraulic equipment.

Provide regular preventive maintenance on hoses and airlines. Exchange hose lines, even if there is no visible damage! (Observe corresponding requirements of the manufacturer!)

After repair and maintenance, check the following items:

- make sure all detached and re-attached connections are solid.
- confirm that removed covers, screens or filters were re-installed
- During disconnecting or reconnecting of an air-operated equipment, injury may occur due to a whipping air-hose

After conclusion of maintenance or repair and prior to start of operation, make sure to

- remove all materials, tools and other supplies needed for the maintenance or repair from work area of the equipment
- remove leaking liquid or oils
- make sure all safety devices on the equipment work perfectly!

## 2.7. Observe Environmental Regulations



When working on or with the equipment, it is imperative to observe all requirements in regards to waste-disposal and proper recycling.

Especially during installation, repair or maintenance, water damaging agents such as

- lubricating grease and oil
- hydraulic fluid
- cooling agents
- solvent-containing cleaning agents

must not leak into the ground or into the sewage system!

Such materials must be stored, transported, contained and recycled in suitable containers.

## 3 Designated Equipment Use

DEPRAG pneumatic pliers are to be used for cutting, bending, sealing/stamping, pressing and mounting of hose/spring clamps.

## 4 Installation

- Blow out air line and pressure hose, prior to connection it to the tool.
- Make sure all air lines have sufficient cross-section (see technical data) and hoses must be free of bends and kinks. The hose length should not exceed 2 meters.
- All DEPRAG Pliers may be operated with lubricated air or non-lubricated. (see paragraph: Maintenance and Upkeep). Best results are achieved, when plier is lubricated with 1 – 2 drops of oil per 1m<sup>3</sup>. When plier is operated with dry air, a performance reduction of up to 20% may occur and maintenance will increase!
- Connect the equipment as follows:
  - a) for standard operation connect to a maintenance unit consisting of filter with condensation reservoir, oiler and pressure regulator. When selecting a maintenance unit, make sure to observe the plier's air consumption requirement (see technical data).

Air Consumption	Thread Size	Part No.
0,05 - 0,5 m <sup>3</sup> /min	G 1/4	820454 A
0,15 – 1,5 m <sup>3</sup> /min	G 1/2	820455 A
0,8 – 4,0 m <sup>3</sup> /min	G 3/4	821608 A

- b) for the use with minimal lubrication connect equipment to a maintenance unit, consisting of Filter with condensation reservoir and Regulator

Air Consumption	Thread Size	Part No.
0,05 - 0,5 m <sup>3</sup> /min	G 1/4	822408 A
0,15 – 0,9 m <sup>3</sup> /min	G 3/8	826981 A
0,5 – 1,5 m <sup>3</sup> /min	G 1/2	822409 A
0,8 – 6,0 m <sup>3</sup> /min	G 3/4	826982 A

Each in connection with a Point-of-Use Oiler (Part No. 378077 A)

- c) For oilfree operation, connect to Filter/Regulator, consisting of Filter with condensation reservoir and Pressure Regulator.

Air Consumption	Thread Size	Part No.
0,05 - 0,5 m <sup>3</sup> /min	G 1/4	822408 A
0,15 – 0,9 m <sup>3</sup> /min	G 3/8	826981 A
0,5 – 1,5 m <sup>3</sup> /min	G 1/2	822409 A
0,8 – 6,0 m <sup>3</sup> /min	G 3/4	826982 A

- Check pressure at directly on the machine. The Regulator needs to be adjusted to an airflow of 6,3 bar (90 PSI). A higher pressure will lead to increased wear and tear. A lower pressure will result in reduced power output.

In regards to air-quality according to ISO8573-1, we recommend:

	CLASS	RESIDUE OF OIL	RESIDUE OF DUST		RESIDUE OF WATER	
		Content mg/m <sup>3</sup>	Particle Size μm	Concentration max. mg/m <sup>3</sup>	Dew Point °C	Pressure Concentration max. g/m <sup>3</sup>
Lubricated Air	4	5	15	8	+3	6
Dry Air	3	1	5	5	-20	0,88

## 5 Operation



### Attention:

Plier starts by activating lever valve. Air flow pressure must not drop beyond 5 bar!

## 6 Handling

The DEPRAG plier is very easy to handle.

Take care to stand securely and hold plier in both hands. Plier insert will open up (close) and cut/treat the material (depending on insert used), once the lever is activated.

After letting go of the lever, plier will be vented and is again ready for use.

## 7 Assembly - Disassembly

**Disassembly:** (see Spare Parts Drawing)



**Prior to disassembly, disconnect equipment from air-supply! Only experienced maintenance personnel may assemble or disassemble this equipment.**

After repair or maintenance, verify that equipment runs to specification!

Principally, use only DEPRAG original spare parts. Otherwise, a reduction in equipment power output and an increased maintenance requirement will occur.


If NON-DEPRAG parts are installed, DEPRAG is entitled to void any existing warranty and liability obligations.

1. Disconnect plier from air supply.
2. Unscrew screws 807771 and remove the two straps 807714.
3. Remove the plier insert pair (Accessories - Optional equipment).
4. Unscrew threaded pin 800543 from housing.
5. Unscrew plier head 807717 from housing.
6. Remove the piston spring 807718.
7. Remove the piston 807720.
8. Push out cylinder pin 800038 from housing.
9. Remove push button 807724.
10. Take out o-ring 807721 and valve pin 807722 from housing.
11. Unscrew threaded plug 807708.
12. Remove o-ring 802504.
13. Remove ball 802187.
14. Remove o-ring 807721.

## **Montage:**

1. Assembly o-ring 807721.
2. Assembly ball 802187.
3. Assembly o-ring 802504.
4. Screw in threaded pin 807708.
5. Assembly o-ring 807721 and valve pin 807722 in the housing.
6. Assembly push button 807724 with cylinder pin 800038.
7. Slide piston 807720 into the housing.
8. Place the piston spring 807718 on the piston.
9. Screw on the plier head 807717.
10. Lock the plier head with threaded pin 800543.
11. Place the plier insert pair (Accessories - Optional equipment) into the plier head.
12. Fix the plier insert pair und the two straps 807714 with the screws 807771 and the nuts 807715.

## 7.1. Spare Parts Drawing



Example spare parts order: 1 off piston 807720



## 8 Maintenance and Upkeep

Testing and maintenance can be provided by Operator. Disassembly and re-assembly of the DEPRAG Plier should be done by experienced maintenance personnel. Incorrect assembly or disassembly may lead to injury of operators and damage the tool.

The tool requires little maintenance. If the following service instructions are observed, the tool will have a long life expectancy and will remain in a safe condition.

- Check tool on a regular basis for external damage.
- Check your maintenance unit on a regular basis, make sure that sufficient oil is in the lubricator (if lubrication is used) and that the adjustment is correct. We recommend for your lubricator DEPRAGOL, part 790081 E (250 cm<sup>3</sup>).
- After cleaning, the moving parts (such as piston) will have to be greased prior to re-assembly, preferably with Grease no.
- After assembly, fill 2 – 3 drops of DEPRAGOL into the air inlet nipple.
- If tool is being used with lubrication, we recommend to have it tested and cleaned every 12 months (single shift).
- If tools are being used without lubrication, we recommend to have them tested and cleaned every 6 months (single shift).
- Exchange broken or worn plier insert immediately, for they may cause injury to the Operator.
- In case of tool malfunctions, we recommend to send the machine to DEPRAG.

### 8.1. Wear Parts

QUANTITY	NAME	PART No.
1	Piston	807720
1	Plier Insert Pair (Accessories are optional equipment)	807678
1	Plier Insert Pair (Accessories are optional equipment)	807679
1	O-Ring 20x2	802543
2	O-Ring 4x2	807721
1	O-Ring 6x2	802504

## 8.2. Trouble Shooting

In the case of a malfunction, check and observe all instructions contained in this technical documentation. If necessary, adjust equipment as needed.

Possible faults and their causes are shown below:

<b>ERROR</b>	<b>REASON</b>	<b>SOLUTION</b>
Plier does not start	No air, Shut-Off valve is closed	Open Shut-Off valve
Insufficient Power	Air pressure too low	Minimum air pressure should be 90 PSI for maximum performance
	Restriction in air hose	Remove bends or other restrictions
	Hose I.D. is too small	Use required hose I.D.
	Plier insert is worn	Exchange plier insert
	Piston is worn	Exchange piston

If necessary, please send tool to DEPRAG for service.

## 9 Delivery Capacity

Please check the delivery capacity in regards to its completeness.

<b>QUANTITY</b>	<b>NAME</b>	<b>PART No.</b>
1	Operating Instruction Booklet	010252 EN
1	Plier	807672 A

## 10 Storage

Unused machines should be stored in a dry, locked area.

## 11 Technical Data

**Manufacturer** DEPRAG SCHULZ GMBH u. CO.  
**Address** Kurfürstenring 12 - 18 Postfach 1352  
D-92224 Amberg D-92203 Amberg  
**Phone** 09621/371-0  
**Fax** 09621/371-120

### Technical Data:

<b>MODEL No.:</b>	<b>48-271</b>
<b>Order-No.:</b>	<b>807672 A</b>
<b>Pressing power (N)</b>	<b>1800</b>
<b>Length (mm)</b>	<b>170</b>
<b>Machine diameter (mm)</b>	<b>35</b>
<b>Weight (kg)</b>	<b>0,21</b>
<b>Air consumption (l) (per stroke)</b>	<b>0,07</b>
<b>Required Hose I.D. (mm)</b>	<b>LW 6 mm</b>
<b>Connecting thread</b>	<b>G 1/4 " i</b>
<b>Air pressure (bar)</b>	<b>6,3</b>

## 12 Disposal

Unused machines should be stored in a dry, locked area. Observe local and environmental regulations for the separation and recycling of materials.



**Recycle waste oil to avoid environmental contamination!**

## 13 Conformity Declaration

### EC-Conformity Declaration according to the EC-Machine-Guidelines 98/37/EC, Amendment IIA

We,

DEPRAG SCHULZ GMBH & CO.  
PO Box 1352  
D-92203 Amberg

hereby confirm, that the design of the  
Plier

**48-271**


conforms to the following, relevant regulation:

- EC-Machine-Guidelines, Version 98/37/EC, Amendment No. 1 and No. 2.2.

Applicable Standard:

- EN 292

Amberg, 11.02. 2004

  
-----  
Dipl. Ing. (FH) A. Lanig  
Mr. Design Dept.

## 14 Service Locations and Authorized Partners

### ARGENTINIEN

#### ERIN s.a.

Av. Constituyentes 5751  
RA-1431 Buenos Aires  
Tel./Fax: +54 (0) 11 / 4573.1313

### AUSTRALIEN

#### De Rossi Industrial Pty. Ltd.

Unit 1 – 2 / 600 Liverpool Road  
Strathfield South, N.S.W. 2136  
Tel.: +61 (0)2 / 8732.7200  
Fax: +61 (0)2 / 8732.7299  
e-mail: [sales@derossi.com.au](mailto:sales@derossi.com.au)

### BELGIEN

#### Aijkens en Zumpolle B.V.

Postbus 29  
NL-5306 ZG  
Brakel/Niederlande  
Tel.: +31 (0)4 18 / 67 18 16  
Fax: +31 (0)4 18 / 67 32 17  
Internet: <http://www.zumpolle.net>  
e-mail: [info@zumpolle.net](mailto:info@zumpolle.net)

### BRASILIEN

#### METALFEMA Ltda.

Rua Saõ Pedro, 786  
Saõ Leopoldo – RS –  
BRAZIL  
ZIP 93.010-260  
Tel.: +55 (0) 51 / 592.4050  
Fax: +55 (0) 51 / 590.1856  
e-mail: [mtfma@zaz.com.br](mailto:mtfma@zaz.com.br)

### CHINA, SUZHOU

#### DEPRAG China

DEPRAG Assembly Technologies Co., Ltd.  
No. 5, Xinghan St, Blk. A#06-16  
Suzhou 215021, P.R. China  
Tel.: +86 (0) 512 – 6767 – 1108  
Fax: +86 (0) 512 – 6767 – 1109  
Internet: [www.deprag.com.cn](http://www.deprag.com.cn)  
e-mail: [biz@deprag.com.cn](mailto:biz@deprag.com.cn)  
e-mail: [d.hua@deprag.com.cn](mailto:d.hua@deprag.com.cn)

### DÄNEMARK

#### DEPRAG Scandinavia AB

Gap Sundins väg 3  
SE-63346 Eskilstuna  
Tel.: +45 (0) 98 57 22 50  
Fax: +45 (0) 98 57 22 53  
Internet: <http://www.deprag.com>  
e-mail: [keld.branner@get2net.dk](mailto:keld.branner@get2net.dk)

### DEUTSCHLAND

#### Werk Amberg

Kurfürstenring 12-18,  
D-92224 Amberg  
Postfach 1352,  
D-92203 Amberg  
Tel.: +49 (0) 9621 / 3 71-0  
Fax: +49 (0) 9621 / 3 71-1 20  
Internet: <http://www.deprag.com>  
e-mail: [info@deprag.de](mailto:info@deprag.de)

### ESTLAND

#### Pneumacon OY

Läkkisepäntie 4  
FI-00620 Helsinki  
Tel.: +358 (0) 9 / 7288.160  
Fax: +358 (0) 9 / 7288.1610  
Internet: <http://www.pneumacon.fi>  
e-mail: [info@pneumacon.fi](mailto:info@pneumacon.fi)  
e-mail: [harry.lindroos@pneumacon.fi](mailto:harry.lindroos@pneumacon.fi)

### FINNLAND

#### Pneumacon OY

Läkkisepäntie 4  
FI-00620 Helsinki  
Tel.: +358 (0) 9 / 7288.160  
Fax: +358 (0) 9 / 7288.1610  
Internet: <http://www.pneumacon.fi>  
e-mail: [info@pneumacon.fi](mailto:info@pneumacon.fi)  
e-mail: [harry.lindroos@pneumacon.fi](mailto:harry.lindroos@pneumacon.fi)

### FRANKREICH

#### DEPRAG France

9, rue du Général Frère  
F-67500 Haguenau  
Tel.: +33 388 / 06.14.17  
Fax: +33 388 / 93.01.08  
e-mail: [depragfrance@evc.net](mailto:depragfrance@evc.net)

### GRIECHENLAND

#### D. Panayotidis – J. Tsatsis s.a.

6 Pireos Street – Moschaton-  
Athen  
Tel.: +30 (0) 1 / 4810.817-8-9  
Fax: +30 (0) 1 / 482 96 73

### GROSSBRITANNIEN

#### DEPRAG Limited

Holly Farm Business Park  
Honiley, Kenilworth  
Warwickshire CV8 1NP  
Tel.: +44 (0) 1926 485480  
Fax: +44 (0) 1926 485481  
Internet: [www.deprag.co.uk](http://www.deprag.co.uk)  
e-mail: [m.searle@deprag.co.uk](mailto:m.searle@deprag.co.uk)

### IRAN

#### NACCARSON AIR TOOLS Co., Ltd.

Azadi Ave. No. 625  
IR-Tehran 14 588  
Tel.: +98 (0) 21 / 6006602 + 6015656  
Fax: +98 (0) 21 / 6009451

### IRLAND

#### Production Equipment Ltd.

Riverside Commercial Estate  
IRL-Galway  
Tel.: +353 (0) 91 / 745 100  
Fax: +353 (0) 91 / 751 299  
e-mail: [sales@productionequipment.ie](mailto:sales@productionequipment.ie)

### ITALIEN

#### DREX PALLOTTI S.r.l

Via A. Manzoni, 19  
I-20090 Vimodrone/Mi  
Tel.: +390 02 / 2740 0561 + 0569  
Fax: +390 02 / 2740 0607  
e-mail: [pallotti@drex.com](mailto:pallotti@drex.com)

### JAPAN

#### NIPPON GESCO Ltd.

P.O. Box 255 Kyobashi Tokyo  
Ginza Matsuyoshi Bldg.  
17 – 8, 7-Chome, Ginza,  
Chuo-Ku, Tokyo  
Tel.: +81 (0) 3 / 3542.2400  
Fax: +81 (0) 3 / 3542.2420  
e-mail: [mail@gesco.co.jp](mailto:mail@gesco.co.jp)

### KOREA (Süd)

#### Handwerkzeuge

#### DONG WON POWER-TECH.INC.

108-10 Moonjung-Dong  
Songpa-Ku  
Seoul, Korea  
Tel.: +82 (0) 2 / 409.1344  
Fax: +82 (0) 2 / 409.1345  
e-mail: [kilpyungdw@dreamwiz.com](mailto:kilpyungdw@dreamwiz.com)  
**Schraubtechnik / Assembly  
Technology Fatec Co.Ltd.**  
#903, Sunglim B/D 257  
Chulsan-Dong  
Kwangmyung-City,  
Kyunggi-Do  
Tel.: +82 (0) 2 / 2 688.2152  
Fax: +82 (0) 2 / 2 688.2842  
e-mail: [fatec@chollian.net](mailto:fatec@chollian.net)  
e-mail: [fatec@fatec.co.kr](mailto:fatec@fatec.co.kr)

### KROATIEN

#### SM AUTOMATIKA D.O.O

Trg i. Kukuljevica 6  
HR-10090 Zagreb  
Tel.: +385(0)13 89 41 79  
Fax: +385(0)13 87 89 78  
Internet: <http://www.sm-automatika.hr>  
e-mail: [info@sm-automatika.hr](mailto:info@sm-automatika.hr)

### LITAUEN

#### HIDROTEKA

P.O. Box 572  
LT-3028 KAUNAS  
Tel.: +370 (0) 37 / 352195  
Fax: +370 (0) 37 / 351952  
e-mail: [hidroteka@hidroteka.lt](mailto:hidroteka@hidroteka.lt)

## LUXEMBURG

**Comptoir Technique et Industriel**  
321, Route d'Arlon  
L-8011 Strassen  
Penang, MALAYSIA  
Tel. +352 / 31 31 40  
Fax: +352 / 31 31 95

## MALAYSIA

**FI INNOVATION ENTERPRISE**  
175, MK D Jalan Bahru  
Balik Pulau 11000  
Penang, MALAYSIA  
Tel. +60/13/ 449.0386 / +60/16/ 403.6797  
Fax: +60/4/ 866.0785  
e-mail: [farisfi@tm.net.my](mailto:farisfi@tm.net.my)

## NIEDERLANDE

**Zumpolle B.V.**  
Postbus 29  
NL-5306 ZG  
Brakel/Niederlande  
Tel.: +31 (0) 4 18 / 67 18 16  
Fax: +31 (0) 4 18 / 67 32 17  
Internet: <http://www.zumpolle.net>  
e-mail: [info@zumpolle.net](mailto:info@zumpolle.net)

## NORWEGEN

**Deprag Scandinavia AB**  
Gap Sundins väg 3  
SE-63346 Eskilstuna  
Universal Import  
Tel.: +47 (0) 2 / 2681.530  
Fax: +47 (0) 2 / 2199.127

## ÖSTERREICH

**Amersin Olschinsky GmbH**  
Carlberggasse 45  
A-1230 Wien  
Tel.: +43 (0)1 / 8 69 87 66  
Fax: +43 (0)1 / 8 65 16 97  
Internet: <http://www.amersin.at>  
e-mail: [information@amersin.at](mailto:information@amersin.at)

## POLEN

**ELKREM SPOLKA Z O.O.**  
ul. Wielki Row 40B  
87-100 Torun  
Tel. +48 / 56 / 662.3881  
FAX +48 / 56 / 662.3882  
e-mail: [elkrem@to.onet.pl](mailto:elkrem@to.onet.pl)

## PORTUGAL

**Anibal Pires Lda.**  
A.P. 23  
E.N. 1 – Mourisca do Vouga  
P-3750 TROFA AGD  
Tel.: +351 (0) 234 / 646.820  
Fax: +351 (0) 234 / 646.815  
Internet: <http://www.anibalpires.pt>  
e-mail: [anibalpires@mail.telepac.pt](mailto:anibalpires@mail.telepac.pt)

## SCHWEDEN

**DEPRAG Scandinavia AB**  
Gap Sundins Väg 3  
S-633 46 Eskilstuna  
Tel.: +46 (0) 16-12 61 10  
Fax: +46 (0) 16-13 31 88  
Internet: <http://www.deprag.se>  
e-mail: [info@deprag.se](mailto:info@deprag.se)

## SCHWEIZ

**Limattec Automation AG**  
Schlachthausstrasse 15  
CH-2540 Grenchen  
Tel.: +41 (0) 32 / 6542904  
Fax: +41 (0) 32 / 6542901  
Internet: <http://www.limattec.ch>  
e-mail: [office@limattec.ch](mailto:office@limattec.ch)

## SINGAPUR

**Testel Systems Pte Ltd**  
1200 Depot Road # 04-07/09  
Singapore 109675  
Tel.: +65 / 6271-3688  
Fax: +65 / 6271-8866  
Internet: <http://www.testel.com.sg>  
e-mail: [sunny@testel.com.sg](mailto:sunny@testel.com.sg)

## SLOWENIEN

**MB-NAKLO D.O.O.**  
Toma Zupana 16  
SLO-4202 NAKLO  
Tel.: +386 (0) 4 / 277 17 00  
Fax: +386 (0) 4 / 277 17 17  
e-mail: [mb-naklo@siol.net](mailto:mb-naklo@siol.net)

## SPANIEN

**ALCOTAN SISTEMAS S.A.**  
pº de la Direccion, nmro. 95,  
local  
E-28039 Madrid  
Tel.: +349 (0) 1 / 311.17.84 + 311.18.01  
Fax: +349 (0) 1 / 311.60.53  
e-mail: [alcotansis@jazzfree.com](mailto:alcotansis@jazzfree.com)

Barcelona office:  
Passeig de la Mare de Déu del  
Coll, 122-124  
E-08023 Barcelona  
Tel.: +349 (0) 3 / 2 19 77 43

## TAIWAN

**I HEN MACHINE Co.Ltd.**  
6F-9, No. 12, Lane 609, Sec. 5  
Chung-Hsin Road,  
San-Chung City  
241 Taipei Hsen  
Tel.: +886 (0) 2 / 2999.6766  
Fax: +886 (0) 2 / 2999.6236

## TSCHECHIEN/SLOWAKEI

**DEPRAG CZ a.s.**  
ul. T.G. Masaryka 113  
CZ -50781 Lázně Bělohrad  
Tel.: +420 (0) 4 93 / 79 24 11  
Fax: +420 (0) 4 93 / 79 25 12  
Internet: <http://www.deprag.com>  
e-mail: [info@deprag.cz](mailto:info@deprag.cz)

## TÜRKEI

**MEKA AUTOMOTIVE ASSEMBLY EQUIPMENTS**  
4. Cadde 67. Sokak 17/1  
Emek 06510 Ankara  
Tel. +90 / 312 / 215.3490  
FAX +90 / 312 / 212.8013  
e-mail: [melih@me-ka-assembly.com](mailto:melih@me-ka-assembly.com)  
[www.me-ka-assembly.com](http://www.me-ka-assembly.com)

## UNGARN

**ADLER '91**  
Export/Import Kereskedelmi  
Takarék u. 18/B  
H-8800 Nagykanizsa  
Tel./Fax: +36 (0) 93 / 314 633  
e-mail: [adler91adlovits@broadband.hu](mailto:adler91adlovits@broadband.hu)

## Nóniusz Tool Trading House Ltd.

Köbányai út. 47/6  
H-1101 Budapest  
Tel.: +36 (0) 1 / 260 030 30  
Fax: +36 (0) 1 / 260 060 83  
Internet: <http://www.noniusz.hu>  
e-mail: [noniusz@noniusz.hu](mailto:noniusz@noniusz.hu)

## USA, MEXIKO, KANADA

**DEPRAG INC.**  
645 Hembry St. / P.O. Box 1554  
Lewisville, TX 75057-4726  
Phone: +1 / 972 / 221 – 8731  
Fax: +1 / 972 / 221 – 8163  
Toll Free: (800) 4 DEPRAG  
Internet: <http://www.deprag.com>  
e-mail: [deprag@depragusa.com](mailto:deprag@depragusa.com)

## VENEZUELA

**Suministros Tecnicos SUMTEC C.A.**  
Av. Francisco de Miranda, Centro Plaza  
Torre C, Piso 16, Oficina C16 A-B  
Urb. Los Palos Grandes  
Caracas 1060  
Tel.: +58 (0) 212 – 28 56 41 0  
Fax.: +58 (0) 212 – 28 51 94 7





---

# DEPRAG

**DEPRAG SCHULZ GMBH u. CO.**

Postfach 1352, D-92203 Amberg

Kurfürstenring 12-18, D-92224 Amberg

☎ (09621) 371-0

Fax (09621) 371-120

Internet: <http://www.deprag.com>

e-mail: [info@deprag.de](mailto:info@deprag.de)



ZERTIFIZIERT NACH DIN EN ISO 9001

---

Feb-04 Änderungen vorbehalten / Technical alterations reserved