

011280 EN

# DEPRAG

## Operating Instruction Booklet

### Pneumatic Screwdriver

343-138U

346482 B

# DEPRAG

**DEPRAG SCHULZ GMBH u. CO.**

Postfach 1352, D-92203 Amberg  
Kurfürstenring 12-18, D-92224 Amberg  
Telefon (09621) 371-0  
Fax (09621) 371-120  
Internet: <http://www.deprag.com>  
e-mail: [info@deprag.de](mailto:info@deprag.de)

**DEPRAG INC.**

P.O. Box 1554 • Lewisville, Texas 75067 – 1554  
645 Hembry Street • Lewisville, Texas 75057 – 4726  
Phone (972) 221 – 8731 • FAX (972) 221 – 8163  
TOLL FREE (800) 4 DEPRAG  
Internet: <http://www.deprag.com>  
e-mail: [deprag@depragusa.com](mailto:deprag@depragusa.com)



CERTIFIED AS PER DIN EN ISO 9001

Jan-04 Technical alterations reserved

## MINIMAT-ULTRA

Dear Customer:

Congratulations, you chose the enclosed tool from an extensive DEPRAG product line . This tool is the result of more than 60 years experience in the design and manufacturing of pneumatic tools for the industrial market. We offer a complete program of pneumatic tools, such as Drills, Tappers, Grinders, Screwdrivers, Impact Wrenches, Metal Working Tools and Hammers.

Please don't hesitate to call on us for all of your needs, from individual hand tools to the complete automated screwdriving cell. Our products offer solutions to any all requirements, which may be needed in the screwdriving sector.

We kindly ask, that you read these operating instructions carefully, so that you will be able to use this tool safely and for many years to come. If you need additional information, please contact your DEPRAG Representative or contact us direct at DEPRAG. We will be happy to answer any questions.

We hope you will be pleased with your new tool!

<b>Table of Content</b>	<b>Page</b>
1. Operating Instruction	2
1.1 Connection + Installation	2
1.2 Operation	3
1.3 Range- and Exchange of Clutch Spring	4
1.4 Torque Adjustment	5
2. Parts Breakdown	7/8
3. Maintenance	6
3.1 General	6
3.2 Testing and Maintenance	6
4. Trouble Shooting	9
5. Safety Tips	10
6. EC-Conformity Declaration	11
7. All important data at a glance	12



Before starting operation of tool make sure to carefully read and follow operating instruction.

### General Information

All DEPRAG MINIMAT-F-ULTRA screwdrivers can be used with or without lubrication. (Please refer to 3.2 Testing and Maintenance)

## 1. Operating Instruction

### 1.1 Connection + Installation


- Blow out air hose before connecting it to the tool.
- The MINIMAT-ULTRA Screwdriver connects as follows:
  - a. Pressure Hose for Driver air. The minimum I.D. needs to be 10 mm (¼"). Please make sure, that the hose is of the right size and not longer than 2 meters (6,6 ft.)
  - b. Function Hose for start impulse (hose I.D. 2.6 mm). Unless otherwise requested the driver is preset to max. torque with the strongest clutch spring.
- Unless otherwise requested the driver is preset to max. torque with the strongest clutch spring.
- The air pressure should be 90 PSI (6,3 bar). A pressure below 90 PSI reduces tool performance, a pressure above 90 PSI increases wear and tear on the tool.

In regards to air-quality according to ISO 8573-1, we recommend:

	Class	Residue of Oil Content mg/m <sup>3</sup>	Residue of Dust		Residue of Water	
			particle size µm	max. concentration mg/m <sup>3</sup>	pressure dewpoint °C	max. concentration g/m <sup>3</sup>
Lubricated Air	4	5	15	8	+3	6
Dry Air	3	1	5	5	-20	0,88

### Attention:

Make sure the hoses allow unrestricted air flow; avoid bends, nicks, etc.



Picture 1: Connection of a DEPRAG MINIMAT-ULTRA Screwdriver

### Operation with Finder and Magnetic Bits: (Picture 4)

To mount the finder (optional equipment)

- unscrew the spring sleeve (left hand thread)
- slide the finder into the spring sleeve, place spring into finder and then re-assemble the spring sleeve.

### 1.2 Operation

The operation of the DEPRAG MINIMAT-ULTRA Screwdriver is very simple. Hold the driver as shown on picture 1 and place the bit into the screw drive. As soon as you push the screwdriver it starts automatically and assembles the screw. When the preset torque is reached, the clutch disengages and the driver stops. After lifting, the driver is ready to start again.

When loosening screw, press the reverse button to the left (see picture 2) before you start the driver. While pressed down, the reverse button may be locked by turning it slightly, so that the screwdriver can be set to continuous left-hand-rotation.

## 7. All important data at a glance

### Technical Data:

Manufacturer: DEPRAG-SCHULZ GMBH & CO.  
 Address: Kurfürstenring 12 - 18 PO Box 1352  
 D-92224 Amberg D-92203 Amberg

Phone: 09621/371-0  
 Fax: 09621/371-120

Subsidiary: DEPRAG INC.  
 Address: 645 Hembry Street  
 Lewisville, TX 75057  
 Phone: (800) 4 DEPRAG = (800) 433-7724  
 Fax: (214) 221-8163

<b>Model No. :</b>	<b>343-138U</b>
<b>Part No.</b>	346492 B
<b>Schrauben</b>	M 5
<b>Length (mm/in)</b>	272
<b>Diameter of motor housing (inches / mm)</b>	1,7 / 44
<b>Weight (kg/lbs)</b>	1,31
<b>Air pressure (bar/PSI)</b>	6,3
<b>Required Hose I.D. (mm/in)</b>	LW 6 ¼"
<b>Torque min. (Nm/in.lbs)</b>	1,0 / 9
<b>Soft pull-up max. (Nm/in.lbs)</b>	2,8 / 24
<b>Hard pull-up max. (Nm/in.lbs)</b>	3,0 / 26
<b>Speed, unloaded (rpm)</b>	4200
<b>Noise level (dB(A))</b>	66
<b>Vibrationen (m/s<sup>2</sup>)</b>	< 2,5
<b>Air consumption (m<sup>3</sup>/min / cfm)</b>	0,4

## 6. EG-Conformity Declaration

### EC-Conformity Declaration according to the EC-Machine-Guidelines 98/37/EC, Amendment IIA

We,

DEPRAG SCHULZ GMBH & CO.  
PO Box 1352  
D-92203 Amberg

hereby confirm, that the  
DEPRAG MINIMAT-ULTRA Pneumatic Screwdriver

343-138U


conform to the following, relevant regulation:


- EC-Machine-Guidelines, Version 98/37/EC, Amendment No. 1 and No. 2.2.

Applicable Standard:

- EN 292

Amberg, 28.01. 2004

  
Dipl. Ing. (FH) A. Lanig  
Mr. Design Dept.



Picture 2: Reverse button as seen from Operator side

The driver has a quick change chuck integrated. After the sleeve 327101 has been pulled toward the tip of the driver (see picture 3), the bit (6,3 mm=¼" hex drive DIN 3126) can be removed or inserted. The spring sleeve has to be unscrewed (left-hand thread).

Before change of bits, disconnect the air. Otherwise the driver may start and possibly cause an injury. Please use only high quality ¼" hex bits.

#### Please note that an injury is possible:

- if the trigger is depressed and the bit is rotating.
- If the driver reacts with an unexpected motion or is damaged.

### 1.3 Range- and Exchange of Clutch Spring

The torque range of the DEPRAG MINIMAT-ULTRA Screwdriver is adjustable. Please see a listing for the torque ranges of the color coded springs below.

#### Torque Range of individual clutch springs: (appx.)

Part	Wire $\varnothing$	Color	Torque minimum	Torque maximum
328026	2,5 mm	green	1,0 Nm	4,0 Nm
328027	2,0 mm	red	1,0 Nm	3,0 Nm

All torque values are based on 90 PSI (6,3 bar) air pressure.


#### Change of Clutch Spring (Picture 3)

Prior to change of clutch spring, disconnect driver from air supply.

1. Unscrew clutch bearing 327100. (left hand thread)
2. Take out clutch 327113 C complete.
3. Put wrench SW 11 onto the hex of the clutch shaft 327084 and unscrew the adjusting nut 327091 with wrench SW 22.
4. Pull off lock ring 327090.
5. Remove clutch spring, replace with new clutch spring and reassemble clutch in reverse order.
6. Push clutch into the clutch bearing and tighten clutch bearing to the motor housing of the screwdriver. (left hand thread)

**Attention:**

The claw of the clutch must engage with the claw of the spindle.




Picture 3: Change of Clutch Springs

**1.4 Torque Adjustment**

1. Disconnect screwdriver from air supply.
2. Dis-assemble the clutch bearing 327100 complete with spring sleeve (left hand thread).
3. Take-out clutch 382707 A complete.
4. Slide wrench SW 11 over the hex and use wrench SW22 to turn the adjusting nut 327091. If adjusting nut is turned to the right (+), the torque will be increased and if turned to the left (-) the torque is decreased.
5. Insert clutch into screw joint and mount clutch bearing complete with spring sleeve to the driver (left hand thread).

**Attention:**

The hex of the clutch must engage with the hex of the spindle.



Picture 5: Actual size of Valve Pin



**Attention:**

When connecting to compressed air supply valve pin may be catapulted out which may cause serious injuries. When checking the actual size of the valve pin make sure to n o t hold the screwdriver towards yourself nor any other person.

Check the actual size only with compressed air connected!

**5. Safety Tips**

The tool is not insulated to protect against an electrical power surge. It is not recommended to use this tool in explosive hazardous environments.

#### 4. Trouble Shooting

<b>Error:</b>	<b>Reason:</b>	<b>Solution:</b>
Screwdriver does not	No air, Shut-Off valve is closed	Open Shut-Off valve
	Clutch is not engaged No push-to-start stroke	Mount clutch correctly Refer to: Range- and exchange of clutch spring
Insufficient Power	Air pressure too low	Minimum air pressure should be 90 PSI for maximum performance
	Restriction in air hose	Remove bends for other restrictions
	Valve Pin too short	Check required length of valve pin according to picture 5. If needed, exchange valve pin.
	Hose I.D. is too small	Use required hose I.D.
	Vanes are worn	Exchange vanes
Driver does not shut-off or ratchets	Air pressure is too low for required torque value	Maintain air pressure of 90 PSI
	Valve Pin is too long	Check length of valve pin, either shorten or replace valve pin

#### 2. Parts Breakdown

Picture 4 (Page 7/8)

#### 3. Maintenance

##### **3.1 General**

Testing and maintenance can be provided by Operator; disassembly and re-assembly of the DEPRAG MINIMAT-ULTRA Screwdriver should be done by experience maintenance personnel. Incorrect assembly or disassembly can lead to injury of an operator and damage of the tool.






##### **We would like to advise, that**

- during any maintenance or repair work, the tool must be disconnected from the air supply.
- during any maintenance or repair work, a clean working surface is recommended. Also, it is not recommended to either eat or smoke during repair or maintenance.

##### **3.2 Testing and Maintenance**

The tool requires little maintenance. If the following service rules are observed, the tool will have a long life expectancy and will remain in a safe condition.

- Check tool on a regular basis for external damage.
- Check your maintenance until on a regular basis, make sure that sufficient oil is in the lubricator (if lubrication is used) and that the adjustment is correct. We recommend for your lubricator DEPRAGOL, part 790081 E. Oiling: approx. 1 - 2 drops per 1 m<sup>3</sup> air consumption.
- If tool are being used with lubrication, we recommend to have tools tested and cleaned every 12 months (single shift).
- If tools are being used without lubrication, we recommend to have tools tested and cleaned every 6 months (single shift).
- After cleaning, the gearing parts have to be greased prior to re-assembly, preferably with Grease, part 807293.
- After assembly fill 2 – 3 drops of DEPRAGOL into the air inlet nipple.
- Exchange broken or worn bits and parts immediately, for they can cause injury to the Operator.



accessories are torque equipment  
spring sleeve cpl. 364673 B

Example spare parts off 5 piece vanes 326953/3

Picture 4: Parts Breakdown  
7/8