

DEPRAG

Operating instructions

Pneumatic screwdriver

346-218-31	352279 A
346-318-31	352279 B
346-518-31	352279 C
346-618-31	352279 D

DEPRAG

DEPRAG SCHULZ GMBH u. CO.

Postfach 1352, D-92203 Amberg
Kurfürstenring 12-18, D-92224 Amberg
Telefon (09621) 371-0
Fax (09621) 371-120
Internet: <http://www.deprag.com>
e-mail: info@DEPRAG.de

DEPRAG INC.

P.O. Box 1554 • Lewisville, Texas 75067 – 1554
645 Hembry Street • Lewisville, Texas 75057 – 4726
Phone (972) 221 – 8731 • FAX (972) 221 – 8163
TOLL FREE (800) 4 DEPRAG
Internet: <http://www.deprag.com>
e-mail: deprag@depragusa.com



CERTIFIED AS PER DIN EN ISO 9001

Apr-01 Technical alterations reserved

MINIMAT-ULTRA

Dear Customer:

Congratulations, you chose the enclosed tool from an extensive DEPRAG product line. This tool is the result of more than 60 years experience in the design and manufacturing of pneumatic tools for the industrial market. We offer a complete program of pneumatic tools, such as Drills, Tappers, Grinders, Screwdrivers, Impact Wrenches, Metal Working Tools and Hammers.

Please call us for all of your needs, from individual hand tools to the complete automated screwdriving cell. Our products offer solutions to any and all requirements, which are needed in the screwdriving sector.

We kindly ask, that you read these operating instructions carefully, so that you will be able to use this tool safely and for many years to come. If you need additional information, please contact your DEPRAG Representative or contact us direct at DEPRAG. We will be happy to answer any questions.

We hope you will be pleased with your new tool!

Table of Content

	Page:
1. Operating Instruction	2
1.1 Safety Tips	2
1.2 Application	2
1.3 Range- and Exchange of Clutch Springs	2
1.4 Bit Change	4
1.5 Torque Adjustment	4
1.6 Connection, Installation and Operation	5
2. Parts Breakdown	7/8
3. Maintenance	10
3.1 General	10
3.2 Testing and Maintenance	10
3.3 Assembly + Disassembly	10
3.4 Special Repair Tools	11
4. Trouble Shooting	12
5. EC-Conformity Declaration/EC-Manufacturer Declaration	13
6. Technical Data/Specifications	14

6. Technical Data/Specifications

Technical Data:

Manufacturer: DEPRAG-SCHULZ GMBH & CO.
 Address: Kurfürstenring 12 - 18 PO Box 1352
 D-92224 Amberg D-92203 Amberg
 Phone: 09621/371-0
 Fax: 09621/371-120

Subsidiary: DEPRAG INC.
 Address: 645 Hembry Street
 Lewisville, TX 75057
 Phone: (800) 4 DEPRAG = (800) 433-7724
 Fax: (214) 221-8163

Model:	346-218-31	346-318-31	346-518-31	346-618-31
Order no.	352279 A	352279 B	352279 C	352279 D
Length: (mm / inches)	175 / 6,8			183 / 7,2
Diameter:	22 mm = 0,87 inches			
Drive:	1/4" female hex			
Weight:	0,5 kg = 1,1 lbs.			
Air Pressure Requirement:	6,3 bar = 90 PSI			
Hose I.D. Requirement:	6 mm I.D. = ¼" I.D.			
Torque min. (Nm / in.lbs):	0,3 / 3	0,3 / 3	0,2 / 2	0,2 / 2
Soft pull-up max. (Nm / in.lbs)	1,0 / 9	1,4 / 12	2,0 / 18	2,0 / 18
Hard pull-up max. (Nm / in.lbs)	1,0 / 9	1,4 / 12	2,0 / 18	2,0 / 18
Speed (rpm):	1900	1300	900	275
Noise Level:	68 dB(A)			
Air Consumption:	0,3 m ³ /min			

5. EC-Declaration of Manufacturer

EC-Declaration of Manufacturer in accordance with the CE-Machine-Guideline 98/37/EWG, appendix II B

DEPRAG SCHULZ GMBH u. CO.
P.O. Box 1352

92203 Amberg, Germany


declares, that the construction of

346-218-31
346-318-31
346-518-31
346-618-31

is appointed to the assembly with another machine and the start of operation of this other machine is prohibited until it is proved that it is in accordance with the CE-Machine-Guideline i.d. F.98/37/EWG.

used standards
- EN 292

Amberg, 02.03. 2001


Dipl. Ing. (FH) A. Langig
Mr. Design Dept.



Before starting operation of tool make sure to carefully read and follow operating instruction.

General Information

All DEPRAG MINIMAT-ULTRA screwdrivers can be used with or without lubrication. (Please refer to 3.2 Testing and Maintenance) Oilfree operation could result in a loss of performance of up to 20 %. To avoid dry running we recommend, especially with a high cycle time, our injection oilers, part no. 37 80 77 A-F (1-6fold). With this oiler you will achieve an optimum lifespan combined with minimum oil consumption.

1. Operating Instruction

1.1 Safety Tips

- The tool is not insulated to protect an electrical power surge.
- It is not recommended to use this tool in explosive hazardous environments.
- The driver is activated immediately when air is connected, this may possibly cause an injury. (provide valve)
- Injury is possible, if the driver reacts with an unexpected motion or is damaged.
- During any maintenance or repair work, or when changing bits, the tool must be disconnected from the air supply.
- During any maintenance or repair work, a clean working surface is recommended. Also, it is not recommended to either eat or smoke during repair or maintenance.
- Unless otherwise requested the driver is preset to max. torque with the strongest clutch spring.

1.2 Application

Screwdriver Spindles are constructed for the stationary use in:

- Lever Operated Single Spindle Screwdriving Stations
- Construction Units
- Multi-Spindle Screwdriving Stations
- Robot End-Of-Arm Tooling
- X-Y-Z Screw-Assembly Stations

These Spindles assemble screws to torque and measure that torque more accurately than any subsequent testing method. They tighten and test the assembly in one operation.

1.3 Range- and Exchange of Clutch Spring

The torque range of the DEPRAG MINIMAT®-Ultra Screwdriver is adjustable. Please see a listing for the ranges of the color coded springs below.

Torque Range of individual clutch springs: (app.)

Part	WireØ	Color	Torque minimum	Torque maximum
323035/1	2,5 mm	green	1,4 Nm=12,4in.lbs.	2,4 Nm=21in.lbs.
323036	2,2 mm	red	0,5 Nm=4,4in.lbs.	1,5 Nm=13in.lbs.
323037	1,6 mm	yellow	0,2 Nm=1,8in.lbs.	0,6 Nm=5,3in.lbs.


All torque values are based on 90 PSI (6,3bar) air pressure.

Attention:

Operate clutch only in specified range with correct clutch spring mounted!

Change of Clutch Spring (Picture 1)

1. Disconnect driver from air supply.
2. Screw-off clutch housing 352275 B with spring sleeve 364671 A and quick change chuck by using hanger 323688. (left-hand thread, see picture 2)
3. Take out clutch 352288 B complete.
4. Press torque setting screwdriver 326240 into the half-round bore of the lock ring 328705/1 and turn in clockwise direction, until the adjusting nut 328704 is unscrewed.
5. Pull off lock ring 328705/1.



Picture 1: Change of clutch Spring

6. Remove clutch spring, replace with new clutch spring and re-assemble clutch in reverse order.
7. Push clutch into the clutch bearing and tighten clutch bearing to the motor housing of the screwdriver. (left hand thread)



Attention:

When connecting to compressed air supply valve pin may be catapulted out which may cause serious injuries. When checking the actual size of the valve pin make sure to not hold the screwdriver towards yourself nor any other person.

Check the actual size only with compressed air connected!

4. Trouble Shooting

Error	Reason	Solution
Screwdriver does not start	No air, Shut-Off valve is closed	Open Shut-Off valve
	Clutch is not engaged	Mount clutch correctly Refer to: Range- and exchange of clutch spring
Insufficient Power	Air pressure too low	Minimum air pressure should be 90 PSI for maximum performance
	Restriction in air hose	Remove bends or other restrictions
	Valve Pin too short	Check required length of valve pin according to picture 6. If needed, exchange valve pin.
	Hose I.D. is too small	Use required hose I.D.
	Screen Support clogged	Clean screen support or exchange with new one
	Vanes are worn	Exchange vanes
Driver does not shut-off or ratchets	Air pressure is too low for required torque value	Maintain air pressure of 90 PSI
	Valve Pin is too long	Check length of valve pin, either shorten or replace valve pin (picture 6)

- Unscrew connector 338457 with allen key AF 6 (right-hand thread).

Attention:

The motor housing could fall down with unscrewed connector 338457.

- Take-out spring 803008, ball 802169 and valve pin 328117 / 328117/1 towards the air-inlet side.
- Take-off sleeve 339853 and silencer at the air inlet side. Take-off motor housing 338450 / 338450/2 of the flange 338455 at the clutch side.
- Push-out motor- and gearing part of the motor housing 338450 towards the clutch side, by using a respective plunger.


Attention:

Motor- and gearing parts could get damaged when falling down.

Assemble the tool in reverse order.

3.4 Special Repair Tools

Wrench	7 mm AF	800400
Wrench	8 mm AF	800399
Wrench	13 mm AF	800404
Wrench	17 mm AF	800405
Wrench	19 mm AF	800408
Allen Key	6 mm AF	800449
Hanger		323688



Picture 6: Actual size of Valve Pin

To be measured under air-pressure.

Attention:

The claw of the clutch must engage with the claw of the spindle.

- The clutch can be adjusted again externally (see 1.5).


1.4 Change of Bits

Attention:

Before exchange of bits, clutch bearing has to be in place and driver needs to be disconnected from air supply.

To change bits, refer to picture 2:

- Unscrew the spring sleeve (left hand thread). This is only necessary if a finder is mounted.
- Pull the sleeve 351890 forward, the bit (6,3mm = 1/4" hex drive) can now be removed or inserted.




Picture 2: Change of Bits

1.5 Torque Adjustment

The required torque for the driver can be adjusted externally as follows:

- Disconnect Screwdriver from air supply.
- Press torque-setting-screwdriver 326240 through one of the three openings of the threaded fitting 338451 into one of the half-round bore. (If necessary, turn Clutch with bit)
- By turning the screwdriver in clockwise direction, the torque is reduced and by turning it counter-clockwise, the torque is increased.



Picture 3: Torque Adjustment

1.6 Connection, Installation and Operation

Blow out air hose before connecting it to the tool.

Connect the MINIMAT®-ULTRA Screwdriver Spindle as follows:

- If used with lubrication, connect driver to Maintenance Unit, consisting of Filter, Regulator and Lubricator.
- If used without lubrication, connect driver to Maintenance Unit, consisting of Filter and Regulator.

The required I.D. of pressure hose is 6 mm (1/4"). Please make sure, that the pressure hose length does not exceed 2 meters (6,6 ft.)

The air pressure should be 90 PSI (6,3 bar). A pressure below 90 PSI reduces tool performance; a pressure above 90 PSI increases wear and tear on the tool.

In regards to air-quality according to ISO 8573-1, we recommend:

	Class	Residue of Oil Content mg/m ³	Residue of Dust		Residue of Water	
			particle size µm	max. concentration mg/m ³	pressure dewpoint °C	max. concentration g/m ³
Lubricated Air	4	5	15	8	+3	6
Dry Air	3	1	5	5	-20	0,88

Attention:

Make sure the hoses allow unrestricted air flow; avoid bends, nicks, etc.

3. Maintenance

3.1 General

Testing and maintenance can be provided by Operator, disassembly and re-assembly of the DEPRAG MINIMAT® ULTRA Screwdriver Spindle should be done by experienced maintenance personnel. Incorrect assembly or disassembly can lead to injury of an operator and damage of the tool.

3.2 Testing + Maintenance

The tool requires little maintenance. If the following service rules are observed, the tool will have a long life expectancy and will remain in a safe condition.


- Check tool on a regular basis for external damage.
- Check your maintenance until on a regular basis, make sure that sufficient oil is in the lubricator (if lubrication is used) and that the adjustment is correct. We recommend for your lubricator DEPRAGOL, part 790081 E. Oiling: approx. 1 - 2 drops per 1 m³ air consumption.
- If tool are being used with lubrication, we recommend to have tools tested and cleaned every 12 months (single shift).
- If tools are being used without lubrication, we recommend to have tools tested and cleaned every 6 months (single shift).
- After cleaning, the gearing parts have to be greased prior to re-assembly, preferably with Grease, part 807293.
- After assembly fill 2 – 3 drops of DEPRAGOL into the air inlet nipple.
- Exchange broken or worn bits and parts immediately, for they can cause injury to the Operator.

3.3 Assembly and Disassembly

Disassemble the screwdriver spindle according the following steps.

Disconnect driver from air supply.

1. Screw-off clutch housing 352275 B complete with spring sleeve 364671 A and quick change chuck by using suspension hook 323688. (Engage in 2 of the 4 holes, left-hand thread)
2. Take out clutch 352288 B complete.
3. Clamp screwdriver horizontally in vice on it's flange 338455 and open threaded fitting 338451 with wrench AF 19 (left-hand thread).
4. Unscrew nipple 323213 with wrench AF17 (right-hand thread).



Picture 5: Spare Parts List