

AST10

-

**Sequence Controller with
integrated Power Supply**

Accessories

-1-

Content

| | |
|---|---|
| 1 Connector Cable AST10 – PC Programming Cable..... | 3 |
| 2 Connector Cable AST10 – PC Data Cable..... | 3 |
| 3 Printer | 3 |
| 4 Toolbox..... | 3 |

1 Connector Cable AST10 – PC Programming Cable

The Programming cable is needed to connect the controller AST10 with the server network or the network port on the PC.

The cable is needed to use the Web-Interface of the controller.

Part-No.: 831902

2 Connector Cable AST10 – PC Data Cable

The data cable is needed to connect the printer port of the AST10 with the COM – port of the PC. This cable is needed to transfer the final values in ASCII-Format from the AST10 to the PC.

Connector Cable RS232

Part-No.: 832415

3 Printer

With an optionally offered printer, the final-values may be printed after each completed assembly sequence.

Printer ND100

Part-No.: 823476

Connector Cable AST30 to ND100

Part-No.: 385452 A

4 Toolbox

The toolbox increases the application possibilities of the AST10 controller on manual stations, as well as in connection with a PLC-controller. The toolbox allows the use of 7 different bits/sockets with a diameter of up to 24mm (AF 19mm), which can be inserted into 7 individual cavities. The selection of the screwdriving program on the AST10 is automatically adapted to the corresponding bit/socket.

Toolbox

Part-No.: 398097 B

Connector Cable AST30 to Toolbox

Part-No.: 385451 A