



# SCREWDRIVER FUNCTION MODULE WITH ELECTRONIC STROKE (E-SFM)






# **ADVANTAGES**

# Flexibility

The Screwdriver Function Module with electronic stroke (E-SFM) has been optimally designed to react flexibly to complex screwdriving tasks, new fasteners and varying assembly requirements.

# Precise parameter control

- force
- speed
- position



# Process reliability

Avoid applying unnecessary stress to your component by optimally adjusting force and speed in your screwdriving application. A gentle engagement process will extend the life of your bit.

# Improved cycle time

Flexible positioning of the bit enables different processing steps to be combined with one another. This can improve the cycle time and increase the productivity of your application.

# One system – many screwdriving directions

Whether downwards or upwards, horizontally or at a particular angle – the E-SFM can do the job without losing the fastener position.

# Integrated depth sensor

The E-SFM can be flexibly programmed and is therefore suitable for various screw heights.

# Suitable for lightweight robots

Due to its low weight, the E-SFM is ideal for use in applications in conjunction with lightweight robots.

# E-SFM manager

Simple parameterisation software in responsive design.

#### **Versions**




#### Without feeding


• if the fastener is pre-positioned

#### With Pick-and-Place

• if the fastener is fed using pick-and-place or via hose and precisely positioned using vacuum tube



nosepiece jaws (MAS)




# With feeding


• mouthpiece with active nosepiece jaws swivel (MASS)


rigid mouthpiece

# **Versions**



#### **Overview**





# **Technical data**

Screwdriver Function Mudule with electronic stroke (E-SFM)						
		Size 16	Size 25 High Performance			
Screw head-ø max.	mm	1	4			
Torque range	Nm	0.01 - 2	2 - 18			
Shaft-ø max.		M8				
Nut max.		M6				
Nosepiece length	mm	40/80				
Free stroke for vacuum	mm	50/100				
Installation position / working direction		any				
Linear axis						
Stroke	mm	100/150/200/250				
Motor attachment		axial/left/right				
Positioning accuracy	mm	± 0,02				
Speed max.	mm/s	700	1500			
Pressure force 1) max.	Ν	45	190			
Pressure force 1) min.	Ν	Self weight of moved mass				
Screwdriver size		19, 22	27, 36			
Feed versions		Without feeding Pick-and-Place With feeding - rigid mouthpiece With feeding - tiltable mouthpiece With feeding - swivel mouthpiece With feeding - mouthpiece with active nosepiece jaws With feeding - mouthpiece with active nosepiece jaws swivel				

<sup>&</sup>lt;sup>1)</sup> The attainable pressure force is dependent on the installation position / working direction.

# **Required Accessories**

Suitable for			size 16	size 25 High Performance	
E-Control	E-SFM digital inputs/outputs	Part no.	119007A	219007A	
E-Control	E-SFM EtherCAT	Part no.	119007B	219007B	
E-Control	E-SFM Profinet	Part no.	119007C	219007C	
E-Control	E-SFM EtherNet/IP	Part no.	119007D	219007D	
E-Control	E-SFM IO-Link	Part no.	119007E	-	
Motor cable	E-SFM length 5m	Part no.		165874	
Motor cable	E-SFM length 8m	Part no.	1658741		
Motor cable	E-SFM length 12m	Part no.	1658742		
Cable	Programming E-Control E-SFM	Part no.	171606		
Software	E-SFM Manager *	Part no.	192336		


<sup>\*</sup> The E-SFM Manager software is not mandatory for parameter transfer via field bus.

#### **Accessories**

### Description - Software E-SFM Manager - material no. 192336

The E-SFM Manager is used for parameter adjustment of movement steps (sequences), as well as to save these on the E-Control.

The software download is available from the myDEPRAG customer portal (my.deprag.com). Registered users can activate the activation code and manage licences in MY ACCOUNT > DEPRAG Apps.



Optionally available software products			
Software TIA Link (activation key)	Material no.	135839	
Software TwinCAT Link (activation key)	Material no.	140996	

#### Optional component for the installation into a switch cabinet - material no. 105452A

#### "Safe stop" module



The "Safe stop" module disconnects the power supply to the linear axis. Power supply for the E-control remains unchanged. Disconnection is implemented with two channels with feedback contacts so that a performance level PL e in accordance with DIN EN ISO 13849-1 with a PFH [1/h] of 4.29E-8 is achieved.

